


PLASTIC PUMP BUCKET PARTS LIST



ITEM NO.	PART NUMBER	PART NAME	QTY.
	PL-1000	PLASTIC PUMP BUCKET	
	PL-1101	PUMP SEAL REPAIR KIT (INCLUDES ***)	
1	PL-1102	PUMP HANDLE	1
2	PL-1103	BOLT, HANDLE/LINK	1
3	PL-1104	PUMP PLUNGER ROD	1
4	PL-1105	HANDLE/PUMP HEAD LINK	2
5	PL-1106	WASHER, HANDLE/PUMP HEAD	3
6	PL-1107	PUMP HEAD BODY	1
7	PL-1108	BOLT, HANDLE/PUMP HEAD	2
8	PL-1109	PRESSURE TUBE	1
9	PL-1110	CHECK VALVE BALL	1
10	PL-1111 *	CHECK VALVE O-RING	1
11	PL-1112	ROLL PIN	1
12	PL-1113	CHECK VALVE BODY	1
13	PL-1114	NUT, HANDLE/LINK	3
14	PL-1115 *	PRESSURE TUBE O-RING	1
15	PL-1116	RUBBER GRIP	1
16	PL-1117 *	PUMP HEAD POLYSEAL	1
17	PL-1118	BOLT, PUMP HEAD	2
18	PL-1119	HOSE ASSEMBLY, DRAIN	1
19	PL-1120	PUMP CONTAINER	1
20	PL-1121	FILL CAP	1
21	PL-1122	CHECK VALVE, EXT. 1/4" NPT	1
22	PL-1123 *	PUMP HEAD SNAP RING	2
23	PL-1124 *	PLUNGER ROD WEAR RING	2
24	PL-1125	CHECK VALVE SEAT	1
25	PL-1126	BOLT, PUMP HEAD SPACER	2
26	PL-1127	PUMP HEAD SPACER	1
27	PL-1128	PUMP HEAD GASKET	1
28	PL-1129	BOLT, HANDLE BRACKET	2
29	PL-1130	NUT, HANDLE BRACKET	2
30	PL-1131 *	STRAINER SCREEN	1
31	PL-1132 *	SCREEN RETAINER	1
32	PL-1133	HANDLE BRACKET	1
33	001VRHA	LIFT HANDLE	1
34	2-HF-101	HEX NIPPLE 1/4" NPT	1
35	2-HF-103	QD MALE COUPLER	1
36	P-029	QD FEMALE COUPLER	1
37	P-033	TURN VALVE 1/4" NPT	1
38	P-036	GAUGE, 3000 PSI	1
39	P-037	BRASS FE CROSS 1/4" NPT	1
40	PH-144	HIGH PRES. HOSE X 144" LG	1

Rev - A (09-10-12)